



Fitting Instructions: Manifestation

Required Tools

A spray bottle and a small quantity of washing up liquid.
A sharp knife or blade.
A tape measure.
Lint free paper towels.
A plastic squeegee.

Preparation

A clean window and a dust free environment is vital to a successful installation. Clean the glass thoroughly before beginning the fitting process. Fill your spray bottle with water and combine with a few drops of washing up liquid.

Installation

1. To ensure your manifestation is applied level and in the correct position, use a tape measure and pen to make temporary marks on the glass.
2. Lay the manifestation on a clean, flat surface, with the application tape facing upwards. Run the squeegee over the design, applying enough pressure to increase the bond between the application tape and the film.
3. Turn over the manifestation and slowly remove the backing sheet.
4. Spray the surface of the manifestation with soapy water solution.
5. Spray the glazing with the soapy water solution.
6. Pick up the manifestation, and apply it to the glazing, using the marks as a guide. The soapy water solution on the film and the glass will help to slide it into the correct position.
7. Once in place, spray the manifestation with water. Then use the squeegee to push out any water or bubbles to the edge of the pane. Continue to squeegee until all moisture is gone.
8. Leave the application tape on for a short time.
9. After a short period of time, slowly peel away the application tape to reveal the manifestation.
10. Use lint free paper towels to dry the window and the frame, being careful not to lift the manifestation at the edges or corners.